


Printer
ACTIVE WEAR

SIZE CHART



Brand: PRINTER ACTIVE WEAR

Style: 2264023 RUN

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
A) body length	68	70	72	74	76	78	80	82	84
B) 1/2 Chest width	46	49	52	55	59	63	67	71	75
C) Sleeve length	16	18	20	21	22	23	24	24,5	25

All measurements are indicative with minimum tolerance of 1 cm